



# KEY BEZEL FOR PORSCHE 911 964 / 993 OUTLAW BACKDATE RESTO-MOD INSTALLATION

## READ BEFORE INSTALLATION

The responsibility for using any Asphalt Killerz product lies entirely with the end user. Asphalt Killerz disclaims any liability for warranty voids or damages that may arise from the use of these products. It is essential to thoroughly examine any area before drilling, as the placement of wiring harnesses and other components can differ significantly. All Asphalt Killerz products are designed exclusively for off-road applications and should be installed by a certified automotive technician.

### Method 1 - Recommended for Stock Vinyl (not pictured but it is the same procedure)



**Step 1** - Unscrew and remove the OEM bezel (Photo 1).

**Step 2** - Secure in place using **clear silicone adhesive** on the back of the Bezel. Align the aluminum Bezel with the “OFF” position at 12 o'clock. (Photo 2)

**Step 3** - Use **blue painter's tape** to hold the bezel while the silicone fully cures. (Photo 3)

**Step 4** - Enjoy your perfectly aligned bezel. (Photo 4)

### Method 2 – Recommended for Alcantara or Aftermarket Materials (preferred method)



**Step 1** - Unscrew and remove the OEM bezel. (Photo 1)

**Step 2** - Install the **included plastic bezel**, tightening lightly (do not overtighten!!!). Add a thin layer of silicone adheshiv on the installed bezel. (Photo 2)

**Step 3** - Align the aluminum Bezel with the “OFF” position at 12 o'clock. (Photo 3)

**Step 4** - Use **blue painter's tape** to hold the bezel while the silicone fully cures. (Photo 4)

**Step 4** - Enjoy your perfectly aligned bezel. (Photo 5)